



QUICK SET PROCEDURES

HOW TO CHANGE, SETTINGS, FOR THE EXPERIENCED BED-CHECK CAREGIVER.

Best done holding the unit with both hands and using both thumbs to press buttons. We recommend setting volumes after setting the tone.

Classic-Check® remembers its current setting after power interruptions.

Actions are in standard type. Classic-Check indications are in italics.

DAY/NITE mode change

1. Press/release the DAY/NITE BUTTON. *Blue light in the splash shield indicates NITE mode.*

ALARM Tone Check (Tone will be identical in DAY and NITE modes.)

1. Press/hold RESET, press/release ALARM, release RESET. (*Hear present alarm tone.*)
2. To silence, press/release RESET again. (*Silence*)

ALARM Tone Check (10 settings. tone will be the same in both DAY and NITE modes.)

1. Press/hold RESET, press/hold ALARM. Do not release either yet.
2. Continue to hold down ALARM, but release RESET, (*Hear present alarm tone.*)
3. While still holding down ALARM, press/release RESET. *Each time you do this, unit will sequence to the next tone setting.* Repeat until hearing desired tone.
4. When reaching desired setting, release ALARM button.
5. Press/release RESET once more to silence and lock in setting. (*Silence*)
6. SUMMARY: The motion is hold middle, hold right, release middle. Press/release middle repeatedly to select a tone. Release all, middle once more to lock.

VOLUME check

1. Set to DAY mode to check day volume or NITE mode to check night volume.
2. Press/hold RESET, press/release VOLUME, release RESET. (*Hear present tone.*)
3. To silence, press/release RESET again. (*Silence*)

VOLUME change (7 separate settings available each for DATE and NITE modes)

1. Set to DAY mode to set day volume or NITE mode to set night volume.
2. Press/hold RESET, press/hold VOLUME. Do not release either yet.
3. Continue to hold down VOLUME, release RESET. (*Hear present volume.*)
4. While still holding down VOLUME, press/release RESET. *Each time you do this, unit will sequence to the next volume setting.* Repeat until hearing desired volume.
5. When reaching desired setting, release VOLUME button.
6. Press/release RESET once more to silence and lock in setting. (*Silence*)
7. SUMMARY: The motion is hold middle, hold left, release middle. Press/release middle repeatedly to select a volume. Release all, middle once more to lock.

DELAY change (1,2, or 3 seconds. Setting will be the same for DAY and NITE modes)

1. The red LEDs marked 1 2 3 indicate the current DELAY setting.
2. Press/release ALARM/DELAY to change the setting.